## **Tele Wiring** SWITCH Neck Bridge S NECK VOL 500K Fold back on to the pot body and solder in place Recommended: Connect under bridge plate NECK TONE 500K **JACK** $\bigcirc$ S = Solder Points Wires from the pickups going to the switch are hot,